



Wood Stove Wall Mount & Cantilever Installation Instructions

Note: We do not recommend installing the Wall Mounted units against cladding or similar material. Rather remove the cladding or similar where the bracket will be installed and mount the unit directly against the brick/plastered wall.

1. Choose the height you would like the unit to be mounted.
2. Hold the bracket against the wall at the desired height and ensure the bracket is level. Once level, mark at least 4 holes with a pen/marker.
3. With a 12mm drill bit, drill the 4 marked areas on the wall at least 60mm deep.
4. The mounting bracket has been supplied with 4x 12mm x 60mm Anchor Sleeve Bolts. Partially insert these bolts into the drilled holes leaving enough of the bolt protruding to simply slide the bracket over into position.
5. Ensure the bracket is level and tighten these bolts, ensuring the thread of the bolt protrudes through the tightening nut creating a secured anchor point.
6. Mount the Curve/Convection Fireplace onto the bracket. Ensure that the mounting slots on the back of the fireplace interlock with the wall mounted bracket.
7. Place the heat deflector onto the wall mounted bracket through the slots provided to decrease the heat from the flue to the rear wall.
8. When installing through the rear exit, the deflector plate can be discarded.

Cantilever

- Supplied in 3 parts, the Convection Wood Stove (which is also common to the Wall Mounted option) simply lifts onto the Cantilever stand and slides into position through the back slots of the unit.
- Prior to fitting the unit to the stand, the slide out drawer should be fitted. See Slide Out Drawer section below to attach the drawer.
- The Cantilever unit is supplied with levelling feet so you can adjust for an uneven floor.
- Prior to fitting the flues, ensure that the unit is safely secured to the Cantilever stand, and the unit is resting level.

Slide Out Drawer

- The slide out drawer comes attached to the Curve Wall Mounted unit. On all other Wall Mounted units and Cantilever units you will need to mount the drawer system to the unit.
- To do so you would simply need to place the unit on its back to access the underside, where you will screw 4 x bolts through the rivnuts in the base of the outerbox of the fireplace. These are supplied with the drawer for each unit.

Updated: 27 Feb 2024

Heat deflector plate

Mounting holes. Make use of at least 2 on each side

Mounting grooves.

Drawer

